
microphone user guide

for all Phonic Ear microphones





- ☐ AT0655 behind-the-neck boom mic
- AT0655M behind-the-neck boom mic with mute
- ☐ AT0655R behind-the-neck boom mic for Radium
- AT0513 over-the-head boom mic
- ☐ AT0795-L infrared lapel mic
- ☐ AT0814 earhook mic
- ☐ AT0814M earhook mic with mute
- ☐ AT0816 FM collar mic
- AT0817 infrared collar mic
- ☐ AT0720 conference mic
- AT0164-L omni-directional lapel mic
- ☐ AT0667-L omni-directional lapel mic
- ☐ AT0291-L directional lapel mic
- **AT0668-L** directional lapel mic





ATO655/ATO655M/ATO655R behind-the-neck boom mic

The AT0655 boom microphone is a lightweight, noise-canceling microphone worn on the head. It is used in very noisy environments or with a sound field system.













If you have the mute feature:




Press and release button to enable/disable mute function (AT0655M only).


AT0513 over-the-head boom mic


The AT0513 boom microphone is a lightweight, noise-canceling microphone worn on the head. It is used in very noisy environments or with a sound field system.















AT0795-L infrared lapel mic


The AT0795-L infrared lapel microphone is a lightweight, noise-canceling microphone worn around the neck. It is used with the VOCALIGHT sound field system.














ATO814/ATO814M earhook mic


The AT0814 boom microphone is a lightweight, noise-canceling microphone worn over the ear. It can be used with SOLARIS, SPRITE, or EASY LISTENER transmitters.














ATO816/ATO817 collar mic (check for availability)


The collar microphone is a lightweight, noise-canceling microphone worn around the neck. It is used in very noisy environments or with a sound field system.
















Press and release button to enable/disable mute function (FM collar mic only).


AT0720 conference mic


The conference microphone is a small, unobtrusive omni-directional condenser microphone. It is designed for communication in meetings, round table discussions, or split-table communications.
















ATO291-L & ATO668-L directional lapel mics ATO164-L & ATO667-L omni-directional lapel mics


The AT0291-L and AT0668-L directional lapel microphones and the AT0164-L and AT0667-L omni-directional lapel microphones are small, lightweight microphones with a windscreen*, clip, and lavalier cord for use with FM transmitters. To reduce the chance of feedback, avoid using omnidirectional lapel microphones with a sound field system. In noisy environments, choose a directional microphone.

directional lapel mics AT0291-L AT0668-L




a








Thread lavalier through Loop lavalier around holes on clip and place neck and clip to mic or around neck clip mic to clothing


omni-directional lapel mics AT0164-L AT0667-L











Loop lavalier around neck and clip to mic **or** clip mic to clothing

u.s.: 800.227.0735, then press 5 • **canada:** 800.263.8700

outside u.s./canada: Call your local Phonic Ear dealer • website: www.phonicear.com

^{*} No windscreen with AT0164-L omni-directional mic