


SYSTEM PLACEMENT

Where you place your Liberty 3 depends on the space you're in.

For a single speaker, place the speaker in front of you. See the illustration below.



If you're using your speakers in a large space, for example on a football field, place the speakers facing the audience, with your receiving/companion speakers 300' (or less) away from the main (AnchorLink transmitting) speaker.

Wireless mics should be within 150' of the main AnchorFlex speaker.

