


723A toteable sound field user guide

Phonic Ear®



troubleshooting

no sound from speaker

- Check receiver volume setting
- Check transmitter on/off control
- Check receiver connections
- Check mute on AT0655M mic
- Check battery polarity
- Recharge or replace batteries
- If using Solaris adapter (AT0799) make sure switch is set to

weak/distorted sounds

- Check receiver volume setting
- Recharge or replace batteries

static

- Check that no other transmitters are transmitting on the same channel


feedback

- Turn down receiver volume
- Move transmitter mic away from receiver speaker


batteries won't charge

- Verify that the charger is plugged into the charge jack and into a working outlet
- Check receiver and transmitter connections
- Check battery polarity
- Make sure that the receiver and transmitter are turned OFF while charging
- Try a different charger
- If using Solaris adapter (AT0799) make sure switch is set to and Solaris is off when charging
- Make sure the batteries are rechargeable NiMH; **never recharge alkaline or disposable batteries — they may rupture and cause damage to your system**

installing batteries



installing PE 300R/350R




charging system

(For best results, charge nightly; charge only rechargeable NiMH batteries)




turn on system




using 572R and 575R (requires AT0799 adapter)
installation and operation for 572R/575R


1 switch settings in receiver back panel




2 attach receiver to toteable using AT0799 adapter



3 switch receiver control to FM



4 set adapter to audio setting



warranty

time period of warranty

This warranty will go into effect upon the date of original purchase of this equipment and will remain in effect for one calendar year from that date as long as the instrument remains the property of the original consumer.

what is covered by this warranty

Any electronic component which, because of workmanship, manufacturing, or design defects, fails to function properly under normal use during the life of this warranty will be replaced or repaired at no charge for parts or labor when returned to the factory service center. Transportation is paid by the customer. If it is determined that repair is not feasible, the entire unit may be replaced with an equivalent unit upon mutual agreement of the manufacturer and customer.

what is not covered by this warranty

This one-year limited warranty does not apply to:

1. Malfunctions resulting from abuse, neglect, or accident.
2. Peripheral accessories as itemized within the product brochure, when such items are returned after 90 days from the original purchase.
3. Instruments connected, installed, used or adjusted in a manner contrary to instructions provided by the manufacturer.
4. Consequential damages and damages resulting from delay or loss of this instrument. The exclusive remedy under this warranty is strictly limited to repair or replacement as herein provided.
5. Products damaged in transit unless investigated by the shipper and returned to the warrantor with the investigation report.

Phonic Ear Inc. reserves the right to make changes in the design or construction of any of its instruments at any time without incurring any obligation to make any changes whatsoever on units previously purchased. This warranty is in lieu of all other expressed warranties. All expressed and implied warranties will terminate upon the expiration of this written warranty. No representative or person is authorized to represent or assume for us any liability in connection with the sale or use of our products other than as set forth above.

what to do if you need service

If you require service under the terms of this warranty, carefully package the instrument to prevent damage in transit and send it postpaid to the nearest factory service center. In your package, include the following: service order or return authorization number, a detailed description of the problem, your full name, billing and shipping address, and telephone number. Customers outside the United States or Canada should contact the nearest Phonic Ear distributor.

charging system

